


ENGINEERING
TOMORROW



User Guide

AK-SM 720 — Boolean logic

ADAP-KOOL® Refrigeration control systems



Application

The function is contained in System manager type AK-SM 720 and can be used for user-defined functions.

The functions can be defined on the basis of the given inputs and outputs, and are limited by the number of the aforementioned inputs and outputs and the grid size.

The user defines the function required. The user must be sufficiently familiar with Boolean logic. Danfoss cannot be held liable for the set-up of the functions.

The logic can be constructed using signals from the following:

- *Direct inputs*

- 4 Pressure inputs (AI)
- 4 Temperature inputs (AI)
- 2 Voltage inputs (AI)
- 32 Digital inputs (DI)

- *Selected application functions*

- e.g. day/night control, defrosting, light control, etc.

- *Internal variables*

- 8 Constants

- 16 Temporary variables

The logic can activate the following signals:

- *Direct outputs*

- 2 Analogue outputs (AO)
- 32 Relay outputs (DO)

- *Selected application settings*


Grid size:

- 20 x 20 fields

Note!

The total number of outputs and Inputs which can be connected to a AK-SM 720 is 80 pcs.

See AK-SM 720 manual for further details.



Content

Application	2
Function units.....	3
Configuration.....	4
Examples	6

Function units

Depending on the type, a function unit can:

- Read an input value
- Perform a calculation
- Forward a value
- Save a set (constant) value
- Save a temporary value
- Activate an output

Contact points

A function unit may have several contact points, which function as inputs and outputs depending on the type.

Signal path

The individual function units are assembled to form a collective function in a grid. Each function unit is executed one by one. Reading takes place from left to right and then down. (The program runs through a complete line before it continues onto the next line.)

Examples



Inputs



I₁ Input signal
E.g. a temperature on an input, a digital signal or the signal from a function.



V₁ Internal variable where a temporary calculation can be used. (Boolean or floating point value)



C₁ Internal constant (Boolean or floating point value)

Output



O₁ Output
E.g. a function, a voltage signal or a relay



V₁ Internal variable where a temporary calculation can be saved. (Boolean or floating point value)

Logical calculations



AND
 $C = A \text{ AND } B$



OR
 $C = A \text{ OR } B$



NOT
 $B = \text{NOT } A$



DELAY
Delays a "TRUE" signal for a number of seconds.
The delay period starts every time the input becomes "TRUE".
The input must be "TRUE" throughout the entire delay period in order for the output to become "TRUE".

Mathematical calculations



Addition
 $C = A + B$



Subtraction
 $C = A - B$



Division
 $C = A / B$



Multiplication
 $C = A \times B$



Greater than
If $A > B$ then $C = \text{TRUE}$, else $C = \text{FALSE}$



Greater than or equal to
If $A \geq B$ then $C = \text{TRUE}$, else $C = \text{FALSE}$



Min.
The smaller value of two input values is reproduced on the output
If $A > B$ then $C = B$, else $C = A$




Max.
The larger value of two input values is reproduced on the output
If $A > B$ then $C = A$, else $C = B$



Avg.
The average of two input values is reproduced on the output.
 $C = (A + B) / 2$

Configuration



Procedure:


1. Highlight a field
2. Insert one of the elements that are shown in the left-hand column (if you select the wrong element, or later want to move the elements around, you can overwrite an element by inserting the "empty" element in place).
3. The settings for the element must then be made. These settings are performed in the right-hand half of the screen. The next page shows the various settings for the elements.
4. Finally, the functions must be started when the configuration has been completed. Press the "Run" button at the top of the screen.

Constants can be changed during operation. Everything else can only be changed when the logic is stopped.


At the bottom of the screen you can see the status of all the defined elements.

*Units for pressure and temperature
e.g. Bar, °C, Psig, °F
All settings and calculations are performed in bar and °C.
They can then be converted to a different unit at a later date.*


There are different settings according to which element is defined.





The program will suggest the next number in the series, but if you want a different reference you can change it here.




- Select Input reference
- Type in name
- Select parameter
- Set "Refresh rate"
- Select Unit
- Press OK
- Remember also to set I/O configuration




During I/O configuration, the position of the connection must be defined.




- Select Output reference
- Type in name (the name is also entered in the output reference)
- Press OK
- Remember also to set I/O configuration



During I/O configuration, the position of the output must be defined.



- Type in name
- Select unit (if necessary)
- Press OK




- Type in name
- Select unit
- Set value
- Press OK


Examples

Thermostat (heating and cooling)

- If the temperature becomes higher than the set temperature for cooling, the relay for cooling will be activated.
- If the temperature becomes lower than the set temperature for heating, the relay for heating will be activated.



Ref.	Parameter	Unit	Value	I/O
I ₄	Bool AI temp 1	Temp		x.x
C ₃		Temp	30	
C ₄		Temp	2	
O ₃	Bool DO 1			x.x
O ₄	Bool DO 2			x.x
Delay			120 sec	
Delay			180 sec.	



Convert a sensor signal to a voltage signal

I3 temperature (AI1)
 C3 reference (22°C)
 C4 amplification (2)
 C5 minimum lower voltage (1)
 C6 maximum upper voltage (9)
 O9 analog output 0-10 V (1-9 V)

Ref.	Parameter	Unit	Value	I/O
I3	Bool AI temp 1	Temp		x.x
C3		Temp	22	
C4		None	2	
C5		None	1	
C6		None	9	
O9	Bool AO 1			x.x

